

Installation and Activation Guide

In this document

- Introductory Setup Steps
- Installing the Software
- Activating the Software



Introductory Setup Steps

 Go to Barcodes.com.au> Label Design Software> NiceLabel designer pro-unlimited users.


URL: https://www.barcodes.com.au/nicelabel-designer-pro-unlimited-users/

2. Click on 'Get Your Free Trial'.


URL: https://www.nicelabel.com/downloads/nicelabel?uid=04535



- 3. Click on Download Free Trial.
- 4. Fill the business details the form requires and click on download now.








Installing the Software

1. Run NiceLabel2019.exe. Installer verifies the installation package content.



- 2. Select installation language from the drop-down list and click ok.
- 3. NiceLabel 2019 Setup dialog window opens automatically. Click Next.
- 4. Select Free Trial as the activation method.
- 5. Select the modules you wish you install.



6. Login using the local user credentials and click next.



If you decide to install NiceLabel Automation, then,

Select how you are going to run Automation.

Type in the account under which the Windows services are going to run. Make sure you use an account with access to printer drivers and label files.

These files must be accessible even if they belong to network shared resources.


NOTE: We recommend using standard or administrative user accounts. The Local System Account has limited access to network shared files and printers.

It requires additional work when setting up printers to make them work correctly.

- Define the installation path and decide if you want to share your usage data with NiceLabel or not. Anonymous usage data helps NiceLabel improve the applications and therefore increase your productivity.
- 8. Click Next to continue and start installation.


Activating the software

1. Click activate to activate your purchased account.





2. Enter your license key (your license key is included in the email that was sent to you after completing the purchase).



TIP: In specific deployment cases – i.e. when installing NiceLabel 2019 in multi-user environments – license key can be read from the installation file name. To achieve this, rename the installation file using the following format: Setup_XXXX-XXXXXX-XXXXXXXXXXXXXXXXXXXXX exe ("X" marks the license key characters). NiceLabel 2019 is automatically configured to use this license